


DISCOVER NUBE



ELECTRICAL RANGE

GENERAL INFORMATION

NUBE

The Nube is a smooth fronted, curved faced steel radiator. Using dry inertia technology, the radiator heats the air in your rooms via a process of convection, offering exceptional warmth and remarkable energy efficiency wrapped up in a single solution.

Product: Electric dry inertia radiator

Pre-installed: Thermostat and a 1,2 m insulated cable with plug.

Also supplied: Brackets, screws, plugs and manual

Control: Control via an integrated thermostat with automatic weekly programming, open window detection,

presence detection and boost function.

Packaging: Every radiator is sturdily packaged in high-quality cardboard. The radiator's characteristics are shown on the label:

electric power - height - length.

Warranty: 10 years for the radiator and 2 years for the electrical components, as long as the installation instructions have

been followed, Henrad's warranty conditions have been met and the radiator is installed outside the splash area.

Paint process: All radiators are degreased, phosphated and powder-coated.

Colours: Traffic white or anthracite grey

Conformity: EcoDesign 2018 (EU Regulation 2015/1188)

Technical data: Voltage 230V ~50Hz, IP24, Class II

Height: 600 mm

Lengths: 470 | 550 | 830 | 1.040 mm

Depth: 83 mm

Output: 700 | 1.000 | 1.500 | 2.000 W

Height	Length	Output	Art. N°.	Colour
H600	L470	700 W	7150B0600010470	Traffic white
			7150D0600010470	Anthracite grey
	L550	1.000 W	7150B0600010550	Traffic white
			7150D0600010550	Anthracite grey
	L830	1.500 W	7150B0600010830	Traffic white
			7150D0600010830	Anthracite grey
	L1040	2.000 W	7150B0600011040	Traffic white
			7150D0600011040	Anthracite grey









ELECTRICAL RANGE

MOUNTING AND INSTALLATION


Since the Nube is a class II heater with an IP24 protection rating, it can be installed as such, in volume 2 or 3 of the bathroom (see figure), provided that it is shielded from water splashes and that the radiator is out reach of persons in the bath or under the shower.

Furthermore, when installed in volume 2, the radiator must additionally be shielded by means of a fixed wall.

The radiator must be installed with the control panel at the top and the electrical wire in the lower section. It is prohibited to install the radiator with the control panel below or on the side.


The appliance is insulated according to class II and is therefore not earthed. It needs to be powered by a single-phased current of 230V \sim 50 Hz.

The plug should be connected to a wall socket placed in volume 3.



ATTENTION:

In France, the installation of electric radiators with plugs is prohibited.







HENRAD